

# GAS FURNACES

80% | 95% | 96%



When the weather gets chilly, you'll get comfortable, consistent heating—and you can also be confident these furnaces are built for durable performance over the long haul.



## 80% SINGLE STAGE UPFLOW HORIZONTAL

Model #	AFUE	BTU Input	Airflow Direction	Dimensions (in.) (H x W x D)
J801X045AU3SAA	80%	45,000	Upflow/Horizontal Right/Left	34.5 x 14.5 x 28
J801X054AU3SAA	80%	55,000	Upflow/Horizontal Right/Left	34.5 x 14.5 x 28
J801X072BU4SAA	80%	72,000	Upflow/Horizontal Right/Left	34.5 x 17.5 x 28
J801X072CU5SAA	80%	72,000	Upflow/Horizontal Right/Left	34.5 x 21 x 28
J801X090BU4SAA	80%	90,000	Upflow/Horizontal Right/Left	34.5 x 17.5 x 28
J801X090CU5SAA	80%	90,000	Upflow/Horizontal Right/Left	34.5 x 21 x 28
J801X108CU5SAA	80%	108,000	Upflow/Horizontal Right/Left	34.5 x 21 x 28
J801X126DU5SAA	80%	126,000	Upflow/Horizontal Right/Left	34.5 x 24.5 x 28

## 80% SINGLE STAGE DOWNFLOW

J801X054AD3SAA	80%	54,000	Downflow	34.5 x 14.5 x 28
J801X072BD4SAA	80%	72,000	Downflow	34.5 x 17.5 x 28
J801X090BD4SAA	80%	90,000	Downflow	34.5 x 17.5 x 28
J801X108CD5SAA	80%	108,000	Downflow	34.5 x 21 x 28
J801X126DD5SAA	80%	126,000	Downflow	34.5 x 24.5 x 28

SEE PAGE 2 FOR SPECIFICATIONS ON THE 95% & 96% FURNACE

- ▶ All furnace models feature a standard silicon nitride igniter
- ▶ Furnace models feature aluminized steel heat exchangers to conduct heat quickly and increase durability
- ▶ Oxbox furnaces are built for flexibility to suit varied installations
- ▶ Furnaces are fully convertible to either natural gas or propane, making them suitable for use in any area
- ▶ Galvanized steel cabinets resist corrosion
- ▶ FER compliant



# GAS FURNACES

80% | 95% | 96%



## 95% SINGLE STAGE UPFLOW HORIZONTAL

Model #	AFUE	BTU Input	Airflow Direction	Dimensions (in.) (H x W x D)
J951X038BU4SAA	95%	38,000	Upflow/Horizontal Right/Left	34.5 x 17.5 x 28
J951X054BU4SAA	95%	54,000	Upflow/Horizontal Right/Left	34.5 x 17.5 x 28
J951X072CU5SAA	95%	72,000	Upflow/Horizontal Right/Left	34.5 x 21 x 28
J951X090CU5SAA	95%	90,000	Upflow/Horizontal Right/Left	34.5 x 21 x 28
J951X108DU5SAA	95%	108,000	Upflow/Horizontal Right/Left	34.5 x 24.5 x 28
J951X120DU5SAA	95%	120,000	Upflow/Horizontal Right/Left	34.5 x 24.5 x 28

## 95% SINGLE STAGE DOWNFLOW

J951X054BD4SAA	95%	54,000	Downflow	34.5 x 17.5 x 28
J951X072CD5SAA	95%	72,000	Downflow	34.5 x 21 x 28
J951X090CD5SAA	95%	90,000	Downflow	34.5 x 21 x 28

## 95% 2-STAGE VARIABLE SPEED UPFLOW HORIZONTAL

J952V060BUVSAA	95%	60,000	Upflow/Horizontal Right/Left	34.5 x 17.5 x 28
J952V080CUVSAA	95%	80,000	Upflow/Horizontal Right/Left	34.5 x 21 x 28
J952V100CUVSAA	95%	100,000	Upflow/Horizontal Right/Left	34.5 x 21 x 28
J952X120DUVSAA	95%	120,000	Upflow/Horizontal Right/Left	34.5 x 24.5 x 28

Our innovative 1-5-10 no-registration warranty gives you maximum peace of mind. Plus, every piece of equipment is warranted to the home, not the homeowner—providing an extra measure of coverage when it comes time to sell.

### WARRANTIES AVAILABLE:

- ▶ **1 Year: Complete Replacement**  
ONLY COMPRESSORS, COILS, OR HEAT EXCHANGER FAILURE
- ▶ **5 Years: Standard Parts Warranty**
- ▶ **10 Years: Compressor Replacement**

## 96% 2-STAGE VARIABLE SPEED DOWNFLOW

J962V060BDVSAA	96%	60,000	Downflow	34.5 x 17.5 x 28
J962V080CDVSAA	96%	80,000	Downflow	34.5 x 17.5 x 28
J962V100CDVSAA	96%	100,000	Downflow	34.5 x 17.5 x 28
J962V115DDVSAA	96%	115,000	Downflow	34.5 x 17.5 x 28

**Questions?** Go to [OXBOXHVAC.COM](http://OXBOXHVAC.COM) for more information.

