



J952V060BUVSAA

HEATING AIRFLOW (CFM) & TEMPERATURE RISE (°F)														
MODEL NUMBER/ HEATING INPUT	MOTOR SWITCH SETTINGS (0=OFF, 1=ON)				EXTERNAL STATIC PRESSURE (in. w.c.)									
					0.1		0.2		0.3		0.4		0.5	
	1	2	3	4	CFM	RISE	CFM	RISE	CFM	RISE	CFM	RISE	CFM	RISE
J952V060BUVSAA 60,000 BTU/hr	0	0	0	0										
	1	0	0	0										
	0	1	0	0										
	1	1	0	0										
	0	0	1	0										
	1	0	1	0	940	56	890	59						
	0	1	1	0	990	53	945	56	905	58				
	1	1	1	0	1,055	50	1,015	52	970	54	930	57	890	59
	0	0	0	1	1,135	47	1,095	48	1,055	50	1,010	52	960	55
	1	0	0	1	1,185	45	1,145	46	1,105	48	1,065	50	1,030	51
	0	1	0	1	1,250	42	1,210	44	1,170	45	1,135	47	1,095	48
	1	1	0	1	1,290	41	1,255	42	1,220	43	1,180	45	1,145	46
	0	0	1	1	1,315	40	1,275	41	1,240	43	1,200	44	1,160	45
	1	0	1	1	1,350	39	1,315	40	1,280	41	1,245	42	1,205	44
	0	1	1	1	1,390	38	1,350	39	1,315	40	1,275	41	1,240	43
1	1	1	1											

COOLING AIRFLOW (CFM)														
MODEL NUMBER/ HEATING INPUT	MOTOR SWITCH SETTINGS (0=OFF, 1=ON)				EXTERNAL STATIC PRESSURE (in. w.c.)									
					0.1	0.2	0.3	0.4	0.5	0.6	0.7	0.8		
	5	6	7	8	(CFM)	(CFM)	(CFM)	(CFM)	(CFM)	(CFM)	(CFM)	(CFM)	(CFM)	
J952V060BUVSAA 60,000 BTU/hr	0	0	0	0										
	1	0	0	0										
	0	1	0	0										
	1	1	0	0	725									
	0	0	1	0	810									
	1	0	1	0	940	890	845	795	750	700				
	0	1	1	0	990	945	905	860	820	775	735	690		
	1	1	1	0	1,055	1,015	970	930	890	845	805	760		
	0	0	0	1	1,135	1,095	1,055	1,010	960	930	890	850		
	1	0	0	1	1,185	1,145	1,105	1,065	1,030	990	950	910		
	0	1	0	1	1,250	1,210	1,170	1,135	1,095	1,055	1,020	980		
	1	1	0	1	1,290	1,255	1,220	1,180	1,145	1,110	1,075	1,040		
	0	0	1	1	1,315	1,275	1,240	1,200	1,160	1,120	1,085	1,045		
	1	0	1	1	1,350	1,315	1,280	1,245	1,205	1,170	1,135	1,100		
	0	1	1	1	1,390	1,350	1,315	1,275	1,240	1,200	1,160	1,125		
1	1	1	1	1,420	1,380	1,345	1,310	1,270	1,235	1,200	1,160			

***NOTES:**

1. Motor switch settings for heating speeds use HEAT switches 1, 2, 3, & 4 and for cooling speeds use COOL switches 5, 6, 7, & 8.
2. To comply with government mandated efficiency standards, two openings are required for airflows above 1,600 CFM.
3. Data is shown without filter.
4. Temperature rises in the table are approximate. Actual temperature rises may vary.
5. Individual cells shaded in gray indicate a temperature rise outside of the recommended range.
6. To comply with government mandated efficiency standards, speed settings shaded in gray are not allowed in HEAT mode.
7. When in low stage heat, the airflow is approximately 70% of the tables high value (2-stage furnaces only).

J952V080CUVSAA

HEATING AIRFLOW (CFM) & TEMPERATURE RISE (°F)														
MODEL NUMBER/ HEATING INPUT	MOTOR SWITCH SETTINGS (0=OFF, 1=ON)				EXTERNAL STATIC PRESSURE (in. w.c.)									
					0.1		0.2		0.3		0.4		0.5	
	1	2	3	4	CFM	RISE	CFM	RISE	CFM	RISE	CFM	RISE	CFM	RISE
J952V080CUVSAA 80,000 BTU/hr	0	0	0	0	1,125	55								
	1	0	0	0	1,205	58	1,120	63						
	0	1	0	0	1,305	54	1,225	57	1,150	61				
	1	1	0	0	1,430	49	1,350	52	1,270	55	1,190	59	1,110	63
	0	0	1	0	1,525	46	1,450	49	1,375	51	1,300	54	1,225	57
	1	0	1	0	1,620	43	1,540	46	1,465	48	1,390	51	1,315	54
	0	1	1	0	1,695	42	1,620	43	1,545	46	1,465	48	1,390	51
	1	1	1	0	1,770	40	1,700	41	1,630	43	1,555	45	1,485	47
	0	0	0	1	1,875	38	1,805	39	1,730	41	1,655	43	1,580	45
	1	0	0	1	1,905	37	1,840	38	1,775	40	1,710	41	1,640	43
	0	1	0	1	1,980	36	1,910	37	1,845	38	1,780	40	1,715	41
	1	1	0	1	2,025	35	1,960	36	1,895	37	1,830	38	1,765	40
	0	0	1	1			2,025	35	1,960	36	1,900	37	1,840	38
	1	0	1	1					2,010	35	1,945	36	1,880	37
	0	1	1	1							2,035	35	1,980	36
	1	1	1	1										

COOLING AIRFLOW (CFM)												
MODEL NUMBER/ HEATING INPUT	MOTOR SWITCH SETTINGS (0=OFF, 1=ON)				EXTERNAL STATIC PRESSURE (in. w.c.)							
					0.1	0.2	0.3	0.4	0.5	0.6	0.7	0.8
	5	6	7	8	(CFM)	(CFM)	(CFM)	(CFM)	(CFM)	(CFM)	(CFM)	(CFM)
J952V080CUVSAA 80,000 BTU/hr	0	0	0	0	1,125	1,040	960	880	795			
	1	0	0	0	1,205	1,120	1,040	960	875	795		
	0	1	0	0	1,305	1,225	1,150	1,070	995	915	840	
	1	1	0	0	1,430	1,350	1,270	1,190	1,110	1,030	950	865
	0	0	1	0	1,525	1,450	1,375	1,300	1,225	1,150	1,075	1,000
	1	0	1	0	1,620	1,540	1,465	1,390	1,315	1,240	1,165	1,090
	0	1	1	0	1,695	1,620	1,545	1,465	1,390	1,315	1,235	1,160
	1	1	1	0	1,770	1,700	1,630	1,555	1,485	1,410	1,340	1,265
	0	0	0	1	1,875	1,805	1,730	1,655	1,580	1,510	1,435	1,340
	1	0	0	1	1,905	1,840	1,775	1,710	1,640	1,575	1,510	1,445
	0	1	0	1	1,980	1,910	1,845	1,780	1,715	1,650	1,580	1,515
	1	1	0	1	2,025	1,960	1,895	1,830	1,765	1,700	1,635	1,570
	0	0	1	1	2,085	2,025	1,960	1,900	1,840	1,775	1,715	1,655
	1	0	1	1	2,135	2,070	2,010	1,945	1,880	1,815	1,750	1,685
	0	1	1	1	2,200	2,145	2,090	2,035	1,980	1,925	1,870	1,820
	1	1	1	1	2,280	2,225	2,170	2,115	2,065	2,010	1,955	1,900

NOTES:

1. Motor switch settings for heating speeds use HEAT switches 1, 2, 3, & 4 and for cooling speeds use COOL switches 5, 6, 7, & 8.
2. To comply with government mandated efficiency standards, two openings are required for airflows above 1,600 CFM.
3. Data is shown without filter.
4. Temperature rises in the table are approximate. Actual temperature rises may vary.
5. Individual cells shaded in gray indicate a temperature rise outside of the recommended range.
6. To comply with government mandated efficiency standards, speed settings shaded in gray are not allowed in HEAT mode.
7. When in low stage heat, the airflow is approximately 70% of the tables high value (2-stage furnaces only).

J952V100CUVSAA

HEATING AIRFLOW (CFM) & TEMPERATURE RISE (°F)														
MODEL NUMBER/ HEATING INPUT	MOTOR SWITCH SETTINGS (0=OFF, 1=ON)				EXTERNAL STATIC PRESSURE (in. w.c.)									
					0.1		0.2		0.3		0.4		0.5	
	1	2	3	4	CFM	RISE	CFM	RISE	CFM	RISE	CFM	RISE	CFM	RISE
J952V100CUVSAA 100,000 BTU/hr	0	0	0	0										
	1	0	0	0										
	0	1	0	0										
	1	1	0	0	1,430	62	1,350	65						
	0	0	1	0	1,525	58	1,450	61	1,375	64				
	1	0	1	0	1,620	54	1,540	57	1,465	60	1,390	63		
	0	1	1	0	1,695	52	1,620	54	1,545	57	1,465	60	1,390	63
	1	1	1	0	1,770	50	1,700	52	1,630	54	1,555	57	1,485	59
	0	0	0	1	1,875	47	1,805	49	1,730	51	1,655	53	1,580	56
	1	0	0	1	1,905	46	1,840	48	1,775	50	1,710	51	1,640	54
	0	1	0	1	1,980	44	1,910	46	1,845	48	1,780	49	1,715	51
	1	1	0	1	2,025	43	1,960	45	1,895	46	1,830	48	1,765	50
	0	0	1	1	2,085	42	2,025	43	1,960	45	1,900	46	1,840	48
	1	0	1	1	2,135	41	2,070	42	2,010	44	1,945	45	1,880	47
	0	1	1	1	2,200	40	2,145	41	2,090	42	2,035	43	1,980	44
1	1	1	1											

COOLING AIRFLOW (CFM)													
MODEL NAME/ HEATING INPUT	MOTOR SWITCH SETTINGS (0=OFF, 1=ON)				EXTERNAL STATIC PRESSURE (in. w.c.)								
					0.1	0.2	0.3	0.4	0.5	0.6	0.7	0.8	
	5	6	7	8	(CFM)	(CFM)	(CFM)	(CFM)	(CFM)	(CFM)	(CFM)	(CFM)	(CFM)
J952V100CUVSAA 100,000 BTU/hr	0	0	0	0	1,125	1,040							
	1	0	0	0	1,205	1,120	1,040						
	0	1	0	0	1,305	1,225	1,150	1,070	995				
	1	1	0	0	1,430	1,350	1,270	1,190	1,110	1,030			
	0	0	1	0	1,525	1,450	1,375	1,300	1,225	1,150	1,075	1,000	
	1	0	1	0	1,620	1,540	1,465	1,390	1,315	1,240	1,165	1,090	
	0	1	1	0	1,695	1,620	1,545	1,465	1,390	1,315	1,235	1,160	
	1	1	1	0	1,770	1,700	1,630	1,555	1,485	1,410	1,340	1,265	
	0	0	0	1	1,875	1,805	1,730	1,655	1,580	1,510	1,435	1,340	
	1	0	0	1	1,905	1,840	1,775	1,710	1,640	1,575	1,510	1,445	
	0	1	0	1	1,980	1,910	1,845	1,780	1,715	1,650	1,580	1,515	
	1	1	0	1	2,025	1,960	1,895	1,830	1,765	1,700	1,635	1,570	
	0	0	1	1	2,085	2,025	1,960	1,900	1,840	1,775	1,715	1,655	
	1	0	1	1	2,135	2,070	2,010	1,945	1,880	1,815	1,750	1,685	
	0	1	1	1	2,200	2,145	2,090	2,035	1,980	1,925	1,870	1,820	
1	1	1	1	2,280	2,225	2,170	2,115	2,065	2,010	1,955	1,900		

NOTES:

1. Motor switch settings for heating speeds use HEAT switches 1, 2, 3, & 4 and for cooling speeds use COOL switches 5, 6, 7, & 8.
2. To comply with government mandated efficiency standards, two openings are required for airflows above 1,600 CFM.
3. Data is shown without filter.
4. Temperature rises in the table are approximate. Actual temperature rises may vary.
5. Individual cells shaded in gray indicate a temperature rise outside of the recommended range.
6. To comply with government mandated efficiency standards, speed settings shaded in gray are not allowed in HEAT mode.
7. When in low stage heat, the airflow is approximately 70% of the tables high value (2-stage furnaces only).

J952X120DU5SAA

HEATING AIRFLOW (CFM) & TEMPERATURE RISE (°F)															
MODEL NUMBER/ HEATING INPUT	MOTOR SWITCH SETTINGS (0=OFF, 1=ON)				EXTERNAL STATIC PRESSURE (in. w.c.)										
					0.1		0.2		0.3		0.4		0.5		
	1	2	3	4	CFM	RISE	CFM	RISE	CFM	RISE	CFM	RISE	CFM	RISE	
J952X120DU5SAA 120,000 BTU/hr	0	0	0	0											
	1	0	0	0											
	0	1	0	0	1,555	68	1,510	70							
	1	1	0	0	1,625	65	1,585	67	1,540	69	1,500	70			
	0	0	1	0	1,690	62	1,650	64	1,610	66	1,570	67	1,530	69	
	1	0	1	0	1,760	60	1,715	62	1,670	63	1,625	65	1,575	67	
	0	1	1	0	1,835	58	1,790	59	1,745	60	1,695	62	1,650	64	
	1	1	1	0	1,885	56	1,840	57	1,790	59	1,745	60	1,700	62	
	0	0	0	1	1,945	54	1,900	56	1,850	57	1,805	58	1,760	60	
	1	0	0	1	1,950	54	1,905	55	1,860	57	1,820	58	1,775	59	
	0	1	0	1	2,075	51	2,030	52	1,990	53	1,945	54	1,900	56	
	1	1	0	1	2,125	50	2,085	51	2,040	52	2,000	53	1,955	54	
	0	0	1	1	2,170	49	2,130	50	2,090	51	2,045	52	2,005	53	
	1	0	1	1	2,215	48	2,180	48	2,140	49	2,105	50	2,070	51	
	0	1	1	1										2,225	47
	1	1	1	1											

COOLING AIRFLOW (CFM)													
MODEL NAME/ HEATING INPUT	MOTOR SWITCH SETTINGS (0=OFF, 1=ON)				EXTERNAL STATIC PRESSURE (in. w.c.)								
					0.1	0.2	0.3	0.4	0.5	0.6	0.7	0.8	
	5	6	7	8	(CFM)	(CFM)	(CFM)	(CFM)	(CFM)	(CFM)	(CFM)		
J952X120DU5SAA 120,000 BTU/hr	0	0	0	0	1,395	1,350	1,305	1,260	1,210	1,165	1,120		
	1	0	0	0	1,465	1,420	1,375	1,330	1,290	1,245	1,200	1,155	
	0	1	0	0	1,555	1,510	1,470	1,425	1,380	1,340	1,295	1,250	
	1	1	0	0	1,625	1,585	1,540	1,500	1,460	1,415	1,375	1,335	
	0	0	1	0	1,690	1,650	1,610	1,570	1,530	1,485	1,445	1,405	
	1	0	1	0	1,760	1,715	1,670	1,625	1,575	1,530	1,485	1,440	
	0	1	1	0	1,835	1,790	1,745	1,695	1,650	1,605	1,555	1,510	
	1	1	1	0	1,885	1,840	1,790	1,745	1,700	1,655	1,610	1,565	
	0	0	0	1	1,945	1,900	1,850	1,805	1,760	1,710	1,665	1,620	
	1	0	0	1	1,950	1,905	1,860	1,820	1,775	1,735	1,690	1,650	
	0	1	0	1	2,075	2,030	1,990	1,945	1,900	1,855	1,810	1,770	
	1	1	0	1	2,125	2,085	2,040	2,000	1,955	1,910	1,870	1,825	
	0	0	1	1	2,170	2,130	2,090	2,045	2,005	1,965	1,925	1,880	
	1	0	1	1	2,215	2,180	2,140	2,105	2,070	2,035	2,000	1,965	
	0	1	1	1						2,225	2,165	21,000	2,040
	1	1	1	1						2,170	2,120	2,065	

NOTES:

1. Motor switch settings for heating speeds use HEAT switches 1, 2, 3, & 4 and for cooling speeds use COOL switches 5, 6, 7, & 8.
2. To comply with government mandated efficiency standards, two openings are required for airflows above 1,600 CFM.
3. Data is shown without filter.
4. Temperature rises in the table are approximate. Actual temperature rises may vary.
5. Individual cells shaded in gray indicate a temperature rise outside of the recommended range.
6. To comply with government mandated efficiency standards, speed settings shaded in gray are not allowed in HEAT mode.
7. When in low stage heat, the airflow is approximately 70% of the tables high value (2-stage furnaces only).